

box with both hangers supplied in this kit. Always use safety tether strap to avoid kayak/ luggage box from toppling.

### Recommendations

Do not climb or hang from the storage racks. It is only intended to store kayaks or luggage boxes, not people.

### Load Ratings

The Kayak Wall Hanger's load capacity is 80kg. Ensure that appropriate fasteners are used to suit the wall type (i.e. brick wall, plasterboard, wood, etc)

### Note for Dealers and Fitters

It is your responsibility to ensure that this fitting instruction is given to the end user or client.


Rhino-Rack 3 Pike Street, Rydalmere, NSW 2116, Australia. (Ph) (02) 9638 4744 (Fax) (02) 9638 4822

Document No: R331 Prepared By: Andy Wana Authorised By: Chris Murty

Issue No: 02 Issue Date: 04/02/2016

These instructions remain the property of Rhino-Rack Australia Pty Ltd and may not be used or changed for any other purpose than intended.

# Rhino-Rack Wall Hanger (RWHL) & (RWHS)





## Rhino-Rack Wall Hanger (RWHL) & (RWHS)

### **Fitting Instruction**

1 For timber walls, we have supplied the countersunk screws to mount the Kayak Wall Hanger onto the wall. Install as follow. For brick, plasterboard and other types of wall, please consult your local hardware store for the appropriate fasteners for this system. **RWHL system shown here.** 

