



к468W Filting Kit

#### **EN** Fitting Instructions for Basic Carrier





x 4








#### MAX kgs (lbs) P W/P WHD US 75 kgs (165 lbs) 75 kgs (165 lbs) EU 75 kgs (165 lbs) 75 kgs (165 lbs) AU 75 kgs (165 lbs) 75 kgs (165 lbs) CN 75 kgs (165 lbs) 75 kgs (165 lbs) NZ 75 kgs (165 lbs) 75 kgs (165 lbs) EU 75 kgs (165 lbs) 75 kgs (165 lbs) NZ 75 kgs (165 lbs) 75 kgs (165 lbs) US 75 kgs (165 lbs) 75 kgs (165 lbs) ZA 75 kgs (165 lbs) 75 kgs (165 lbs) AU 75 kgs (165 lbs) 75 kgs (165 lbs) CN 75 kgs (165 lbs) 75 kgs (165 lbs)


#### Mercedes-Benz


GL X164, 5dr SUV 06-+ GL X164, 5dr SUV 06-15 GL X164, 5dr SUV 06-15 GL X164, 5dr SUV 06-15 GL X164, 5dr SUV Jul 06-15 **Skoda** Yeti, 5dr SUV 09-+ Yeti, 5dr SUV 09-+ Yeti, 5dr SUV 09-+ Yeti, 5dr SUV 09-+

Yeti, 5dr SUV 14-17

2







GL X164, 5dr SUV 06-15 (EU) GL X164, 5dr SUV 06-15 (AU) GL X164, 5dr SUV 06-15 (CN) GL X164, 5dr SUV Jul 06-15 (NZ) Yeti, 5dr SUV 09-+ (EU) Yeti, 5dr SUV 09-+ (NZ) Yeti, 5dr SUV 09-+ (US)

GL X164, 5dr SUV 06-+ (US)

Yeti, 5dr SUV 09-+ (ZA)

Yeti, 5dr SUV 09-+ (AU)

Yeti, 5dr SUV 14-17 (CN)

Α	В	С	1	2	3
-	-	-	855mm	795mm	-
-	-	-	33 11/16ths"	31 5/16ths"	-
-	-	-	855mm	795mm	-
-	-	-	33 11/16ths"	31 5/16ths"	-
-	-	-	855mm	795mm	-
-	-	-	33 11/16ths"	31 5/16ths"	-
-	-	-	855mm	795mm	-
-	-	-	33 11/16ths"	31 5/16ths"	-
-	-	-	855mm	795mm	-
-	-	-	33 11/16ths"	31 5/16ths"	-
50mm	800mm	-	815mm	805mm	-
2"	31 1/2ths"	-	32 1/16ths"	31 11/16ths"	-
50mm	800mm	-	815mm	805mm	-
2"	31 1/2ths"	-	32 1/16ths"	31 11/16ths"	-
50mm	800mm	-	815mm	805mm	-
2"	31 1/2ths"	-	32 1/16ths"	31 11/16ths"	-
50mm	800mm	-	815mm	805mm	-
2"	31 1/2ths"	-	32 1/16ths"	31 11/16ths"	-
50mm	800mm	-	815mm	805mm	-
2"	31 1/2ths"	-	32 1/16ths"	31 11/16ths"	-
50mm	800mm	-	815mm	805mm	-
2"	31 1/2ths"	-	32 1/16ths"	31 11/16ths"	-

## **First Time Installation**



 Remove parts from inside the package and check. Contact your dealer if any parts are missing or damaged.

- Ensure the roof rack face towards the front of vehicle.
- This product has two different bar lengths. The longer bar should be used on the front of the vehicle and the shorter bar used on the rear.



- Use keys to remove covers.
- While holding the key in the vertical position, pull the cover towards you to remove the cover.
- Repeat for all legs.



• Locate the Hex Key in one of the roof rack legs.



- Extend the leg out.
- Remove Hex Key by lifting and sliding out.



- Remove existing bolt and replace with bolt supplied with fitting kit
- Just engage with nut
- Do not tighten at this stage

## Fitment



- Position one end of crossbar on the opposite roof rail and swing the free end so that the clamp is under the rail and the rubber gasket sits on top.
- Repeat on other crossbar.
- Crossbars should be parallel to each other and sit perpendicular to the roof rails.



- Pull legs out evenly until both rubber gasket seal on roof rail.
- Ensure each end of the crossbar is adjusted equally.
- Note that legs can pivot slightly to accommodate for roof rail taper.



- Once crossbars are in position, tighten screw to 5 Nm (3.7 ft lb).
- Repeat for all legs.



 Slide Hex Key back into position into one of the roof rack legs.

- Ensure the locks on the legs are in the locked position (horizontal).
- Slide cover into the leg, You will hear a 'click' when the cover is securely locked.
- Repeat for all four positions.



• Check crossbar is securely attached to the vehicle.

CAUTION: Recheck all fasteners immediately after a load is applied to the crossbars. Regularly check screws are tight.

#### Maintenance

- Long loads should be secured with nonelastic straps to the front and rear of the vehicle.
- Objects with pointed ends (e.g. ski poles) should be carried with the pointed ends to the rear of the vehicle.
- Remove all loose or removable objects from the load prior to loading.
- Make sure all loads are securely fastened with non-elastic straps. Check regularly during longer journeys.
- A loaded roof rack system can alter the performance of your vehicle. Be especially aware of the effects of side winds, changing of direction, and braking performance. Avoid rapid acceleration and deceleration. Drive carefully.
- Note that the total height of the vehicle increases when upright loads are carried.
- Products should be locked during transport if they have locks fitted.
- Check and replace worn out or defective parts.
- Keep the product clean and maintained.
- Never drive into a car wash with the roof rack system fitted.
- Lubricate locks and adjusting screws at regular intervals.
- Remove the products from the vehicle when not in use. Make sure all loose parts are stored safely.
- Clean the car roof and surfaces of the product that will be in contact with the car roof.
- Follow the fitting instructions for fitting the product to your vehicle. Make sure all steps are carried out in order.
- Set crossbars a minimum distance of 700mm (27 1/2") apart where no other distance is specified in the fitting instructions. This is especially important when carrying long loads.
- Check unit is securely attached whenever you refit it to the vehicle. If the unit feels loose, refer to the fitting instructions and readjust.

- Some glass/panoramic roofs and radio antennae may not be able to be used when the product is fitted.
- Do not modify this product.
- Refer to the maximum permitted load capacity specified in the fitting instructions. Do not exceed the vehicle manufacturers roof load rating if it is lower than the maximum load capacity specified in the fitting instructions.
- Loads should not overhang the sides of the product and be evenly distributed with the lowest possible centre of gravity.

### Accessories Available for this Product:

- Roof Box
- Ski, Snowboard Carrier
- Canoe, Kayak Carrier
- Bicycle Carrier
- For more accessories please see our product catalogue.
- Yakima Products, Inc. 4101 Kruse Way, Lake Oswego, OR 97035 USA

www.whispbar.com www.whispbar.ca